


Movement cal. 2623 / 2628

Technical Specifications:

Diameter: 26mm , Height 7,75mm, 17 Jewels,
Manual winding, central second-hand, shock resistance and date indicator
2623 /+ 24-hour watch, 2628 /+ week-day indicator,
21.600 vph; Accuracy is about -20 to +60 seconds per day
Power reserve 40 hours



2623



2628

Manual

1. The watch is wound up by turning the crown clockwise.
2. To set the time pull out the crown and adjust the time. After that press the crown in its initial position. (*Note for watches with screwed-in crown: first unscrew the crown counterclockwise, then adjust the time by rotating the hands clockwise, finally screw the crown back while slightly pressing it.*)
3. The date – and the week-day indicator automatically switch once a day
4. Setting/adjusting the date **cal. 2623**
 - Pull out / unscrew the crown.
 - Turn hands until the next date appears /Check that **a.m.** period is set (the date changes once in 24 hours) by turning the hands clockwise past the 12 o'clock marker; if the date changes the time is set for the **am.** period. If the date does not change, the time is set for the **p.m.** period and you should turn the hour hand for one more 12-hour-circle./
 - To set/change the date for several days turn hands clockwise and counterclockwise alternatively in the range 12h–7h–12h until the next day's date appears. Repeat this till you reach the desired date

Pull in/screw-in the crown.

Cal. 2628

Adjusting the date:

On the left side of the case you will find a pusher to adjust the date.

Adjusting the week-day:

Use 4. Setting/adjusting the date explained in **cal. 2623** to set the week-day

Explanation of Russian abbreviations for week-days in English:

ПНД (Понедельник) – **Monday**; **ВТР** (Вторник) – **Tuesday**; **СРД** (Среда) – **Wednesday**; **ЧТВ** (Четверг) – **Thursday**; **ПТН** (Пятница) – **Friday**; **СУБ** (Суббота) – **Saturday**; **ВСК** (Воскресенье) - **Sunday**

WARNING:

STOP rotating the hands at the moment when the time-disc begins to move and the date changes! Wait till the date is changed, then continue adjusting/setting the time/date.

Do not use any force to wind up the watch. The watch is completely wound-up when you feel slight resistance.

If you follow these instructions and use the watch carefully it will work trouble-free and keep high accuracy for a long time.